

## SPARE PARTS AND ACCESSORIES





## Spare parts:

|   | <b>CH105K</b><br>Wrench for nozzle replacement   | quantity:<br>1 |
|---|--|----------------|
|   | <b>DUS07-xx</b><br>Nozzle 1,3-2,5mm.   | quantity:<br>1 |
| 0 | MRK01<br>KIT cap for paints/varnishes<br>- Blue cap for water paints /varnishes<br>- Chromed ring nut for spray guns | quantity:<br>1 |
|   | <b>MRK10</b><br>Assembled nylon tank 0,6lt spray gun   | quantity:<br>1 |



## Accessories:

|   | <b>DEN01K</b><br>Densimeter for varnishes  | quantity:<br>1 |
|---|--|----------------|
| ₩ <sup>\$</sup> ₩ <sup>\$</sup> ¢ <sup>\$</sup> ¢ | <b>DUS07</b><br>Nozzles Ø 0,5-0,7-1-1,3-1,7-2,1-3-3,5 mm   | quantity:<br>1 |
| J   | <b>GUS02K</b><br>Heat resistant grip for spray guns  | quantity:<br>1 |
|   | <b>MRK02</b><br><i>KIT cap for varnishes</i><br>- <i>Red cap for varnish - spray guns</i><br>- <i>Chromed ring nut for spray guns</i>  | quantity:<br>1 |
| •• • • •  | MRK03 for all HVLP spray guns<br><i>KIT Needle Assembly spray gun HVLP</i><br>- Nickel plated stuffing box for spray guns<br>- Needle gasket for spray guns<br>- O -ring for spray guns<br>- Assembled needle for spray guns<br>- Washer for spray guns<br>- Back plug for spray guns<br>- Needle spring for spray guns  | quantity:<br>1 |
| fr.   | MRK04 for all spray guns HVLP<br>KIT Trigger Assembly HVLP<br>- Trigger assembly for spray guns<br>- Lever screw for spray guns  | quantity:<br>1 |
|   | MRK08 for all HVLP spray guns<br><i>KIT gaskets spray guns HVLP, ACT HVLP and AXV LVLP</i><br><i>(all)</i><br>- 2 Needle gasket for spray guns<br>- 2 Spring gasket for spray guns (NEW)<br>- 2 O-ring for spray guns<br>- 2 Tankholding gasket spray gun<br>- 2 Eight-shaped gasket(MRI)<br>- 2 Gasket for surge tank lock cover MRI-AS, ACT-AS and<br>AXV-AS | quantity:<br>1 |
|   | <b>KIT07K per aerografi HVLP</b><br>Radiator kit for spray guns (for a better yield it's<br>recommended the use of MRS and MBA spray guns)   | quantity:<br>1 |





quantity: 1

